

BLANK PAGE



भारतीय मानक

सतह रंदा तथा मोटाई देने की काष्ठकर्म मशीनों का परीक्षण चार्ट

(पहला पुनरीक्षण)

Indian Standard

TEST CHART FOR WOODWORKING SURFACE PLANING AND THICKNESSING MACHINES

(First Revision)

UDC 674.056: 621.952.252: 620.1 (084.3)

© BIS 1992

BUREAU OF INDIAN STANDARDS

MANAK BHAVAN, 9 BAHADUR SHAH ZAFAR MARG NEW DELHI 110002

NATIONAL FOREWORD

auxiliary machines (see Note)

This Indian Standard (First Revision) which is identical with ISO 7570: 1986 'Woodworking machines — Surface planing and thicknessing machines — Nomenclature and acceptance conditions' issued by the International Organization for Standardization (ISO), was adopted by the Bureau of Indian Standards on the recommendations of the Woodworking Machines Sectional Committee (PE 01) and approval of the Production Engineering Division Council.

This standard was first issued in 1974. Consequent upon the publication of ISO 7570: 1986, this standard has been revised by adopting ISO 7570: 1986 to bring it in line with ISO standard. In this revision, clause references of ISO 230-1: 1986 for method of tests has been incorporated which were not there earlier.

The text of ISO standard has been approved as suitable for publication as Indian Standard without deviations. Certain conventions are, however, not identical to those used in Indian Standards. Attention is particularly drawn to the following:

- a) Wherever the words 'International Standard' appear referring to this standard, they should be read as 'Indian Standard'.
- b) Comma (,) has been used as a decimal marker in ISO Standard while in Indian Standard the current practice is to use a point (.) as the decimal marker.

In this adopted standard, reference appears to certain International Standards for which Indian Standards exist. The corresponding Indian Standards which are to be substituted in their place are listed below along with their degree of equivalence for the editions indicated:

International Standard

Indian Standard

Degree of Correspondence

ISO 230-1: 1986

IS 2063: 1988 Code for testing machine tools (first revision)

ISO 7984: 1988 Woodworking machines — Technical classification of woodworking and

NOTE — The technical committee responsible for the preparation of this standard has decided that the provisions of this ISO standard, is acceptable for use in conjunction with this standard.

Only the English language text of the International Standard has been retained while adopting it as Indian Standard.

Indian Standard

TEST CHART FOR WOODWORKING SURFACE PLANING AND THICKNESSING MACHINES

(First Revision)

1 Scope and field of application

This International Standard specifies the appropriate terminology for each part of the machine and, with reference to ISO 230/1, the geometrical tests for surface planing and thicknessing machines; it also gives the corresponding permissible deviations which apply to machines of general purpose use and normal accuracy.

This International Standard deals only with the verification of accuracy of the machine. It does not apply to testing the running of the machine (vibrations, abnormal noises, stick-slip motion of the components, etc.), nor to its characteristics (speeds, feeds, etc.) which should generally be checked before testing accuracy.

This International Standard does not impose any practical test for surface planing and thicknessing machines. Practical tests should be exceptions and have to be stated in a previous agreement between the manufacturer and the user.

This International Standard applies to those machines designated by the number 12.81 in ISO 7984.

2 References


ISO 230/1, Acceptance code for machine tools — Part 1: Geometric accuracy of the machine operating under no load or finishing conditions.

ISO 7984, Woodworking machines — Technical classification of woodworking and auxiliary machines. 1)

3 Preliminary remarks

- 3.1 In this International Standard all dimensions and permissible deviations are expressed in millimetres.
- 3.2 To apply this International Standard, reference should be made to ISO 230/1, especially for installation of the machine before testing, the warming up of the main spindle and other moving parts, and description of measuring methods. The measuring instruments shall not permit errors over 1/3 of the tolerances being checked.
- **3.3** The sequence in which the geometrical tests are given is related to the sub-assemblies of the machine and this in no way defines the practical order of testing. In order to make the mounting of instruments or gauging easier, tests may be applied in any order.
- 3.4 It is not always possible nor necessary to carry out all the tests given in this International Standard.
- 3.5 It is up to the user to choose, in agreement with the manufacturer, those tests relating to the properties which are of interest to him, but these tests shall be clearly stated when ordering a machine.
- **3.6** A movement is longitudinal when it takes place in the working direction of the piece.
- 3.7 When establishing the tolerance for a measuring range different from that given in this International Standard (see clause 2.311 in ISO 230/1), it should be taken into consideration that the minimum value of the tolerance is 0.01 mm.

4 Nomenclature



Reference Surface planing and thicknessing machines 1		English
1.1 Main frame 2 Feed of workpiece and/or tools 2.1 Infeed feed roller 2.2 Outfeed feed roller 2.3 Thicknessing table rollers 2.4 Table extension roller 2.5 Feed roller drive chain 2.6 Feed roller drive sprockets 2.7 Tensioning roller sprockets 2.8 Speed reduction gearbox or variable speed gear 2.9 Outfeed roller drive sprockets 3 Workpiece; support clamp and guide 3.1 Thicknessing table 3.2 Infeed surfacing table 3.3 Surfacing table lip plates 3.4 Outfeed surfacing table 3.5 Canting fence 4.0 Fence gauge plates 3.7 Infeed pressure bar 3.8 Outfeed pressure bar 3.9 Table extension support arm 4 Tool-holders and tools 4.1 Cutterblock 4.2 Cutterblock wedge 4.3 Blade 5 Workheads and tool drives 5.1 Cutterblock bearing 6 Controls 6.1 Starting switch 6.2 Isolating switch 6.3 Surfacing table vertical adjustment 7 Thicknessing table rollers vertical adjustment 6.6 Fence fine adjustment 7 Fence fine adjustment 7 Fence canting adjustment 8 Surfacing table drawback lock 8 Fence transverse lock 7 Safety devices 7.1 Cutterblock guard (bridge guard) 7.2 Cutterblock rear guard 7.3 Anti-kick-back fingers 7.4 Cut depth limiter Miscellaneous Dust extraction outlet Access door to control gear	Reference	
1.1 Main frame 2 Feed of workplece and/or tools 2.1 Infeed feed roller 2.2 Outfeed feed roller 2.3 Thicknessing table rollers 2.4 Table extension roller 2.5 Feed roller drive chain 2.6 Feed roller drive sprockets 2.7 Tensioning roller sprockets 2.8 Speed reduction gearbox or variable speed gear 2.9 Outfeed roller drive sprockets 3 Workplece: support clamp and guide 3.1 Thicknessing table 3.2 Infeed surfacing table 3.3 Surfacing table lip plates 3.4 Outfeed surfacing table 3.5 Canting fence 3.6 Fence gauge plates 3.7 Infeed pressure bar 3.8 Outfeed pressure bar 3.9 Table extension support arm 4 Tool-holders and tools 4.1 Cutterblock 4.2 Cutterblock wedge 4.3 Blade 5 Workheads and tool drives 5.1 Cutterblock bearing 6 Controls 6.1 Starting switch 6.2 Isolating switch 6.3 Surfacing table vertical adjustment 7 Thicknessing table vertical adjustment A Thicknessing table vertical adjustment 5 Thicknessing table rollers vertical adjustment 6.6 Fence canting adjustment 7 Fence fine adjustment 8 Surfacing table drawback lock 7 Fence transverse lock 7 Safety devices 7.1 Cutterblock guard (bridge guard) 7.2 Cutterblock rear guard 7.3 Anti-kick-back fingers 7.4 Cut depth limiter 8 Miscellaneous 8.1 Dust extraction outlet Access door to control gear		and thicknessing machines
2.1 Infeed feed roller 2.2 Outfeed feed roller 2.3 Thicknessing table rollers 2.4 Table extension roller 2.5 Feed roller drive chain 2.6 Feed roller drive chain 2.6 Feed roller drive sprockets 2.7 Tensioning roller sprockets 2.8 Speed reduction gearbox or variable speed gear 2.9 Outfeed roller drive sprockets 3 Workpiece: support clamp and guide 3.1 Thicknessing table 3.2 Infeed surfacing table 3.3 Surfacing table lip plates 3.4 Outfeed surfacing table 3.5 Canting fence 3.6 Fence gauge plates 3.7 Infeed pressure bar 3.8 Outfeed pressure bar 3.9 Table extension support arm 4 Tool-holders and tools 4.1 Cutterblock 4.2 Cutterblock wedge 4.3 Blade 5 Workheads and tool drives 5.1 Cutterblock bearing 6 Controls 6.1 Starting switch 6.2 Isolating switch 6.3 Surfacing table vertical adjustment 7 Thicknessing table vertical adjustment 7 Thicknessing table rollers vertical adjustment 6.6 Fence canting adjustment 6.7 Fence canting adjustment 6.8 Surfacing table drawback lock 6.9 Fence transverse lock 7 Safety devices 7.1 Cutterblock guard (bridge guard) 7.2 Cutterblock rear guard 7.3 Anti-kick-back fingers 7.4 Cut depth limiter 8 Miscellaneous 8.1 Dust extraction outlet 8.2 Access door to control gear	1	Framework
2.1 Infeed feed roller 2.2 Outfeed feed roller 2.3 Thicknessing table rollers 2.4 Table extension roller 2.5 Feed roller drive chain 2.6 Feed roller drive sprockets 2.7 Tensioning roller sprockets 2.8 Speed reduction gearbox or variable speed gear 2.9 Outfeed roller drive sprockets 3 Workpiece; support clamp and guide 3.1 Thicknessing table 3.2 Infeed surfacing table 3.3 Surfacing table lip plates 3.4 Outfeed surfacing table 3.5 Canting fence 3.6 Fence gauge plates 3.7 Infeed pressure bar 3.8 Outfeed pressure bar 3.9 Table extension support arm 4 Tool-holders and tools 4.1 Cutterblock 4.2 Cutterblock wedge 8lade 5 Workheads and tool drives 5.1 Cutterblock bearing 6 Controls 6.1 Starting switch 6.2 Isolating switch 6.3 Surfacing table vertical adjustment 7 Thicknessing table vertical adjustment 6.4 Thicknessing table vertical adjustment 6.5 Thicknessing table rollers vertical adjustment 6.6 Fence canting adjustment 6.7 Fence canting adjustment 6.8 Surfacing table drawback lock 6.9 Fence transverse lock 7 Safety devices 7.1 Cutterblock guard (bridge guard) 7.2 Cutterblock rear guard 7.3 Anti-kick-back fingers 7.4 Cut depth limiter 8 Miscellaneous 8.1 Dust extraction outlet 8.2 Access door to control gear	1.1	Main frame
2.2 Outfeed feed roller 2.3 Thicknessing table rollers 2.4 Table extension roller 2.5 Feed roller drive chain 2.6 Feed roller drive sprockets 2.7 Tensioning roller sprockets 2.8 Speed reduction gearbox or variable speed gear 2.9 Outfeed roller drive sprockets 3 Workpiece: support clamp and guide 3.1 Thicknessing table 3.2 Infeed surfacing table 3.3 Surfacing table lip plates 3.4 Outfeed surfacing table 3.5 Canting fence 3.6 Fence gauge plates 3.7 Infeed pressure bar 3.8 Outfeed pressure bar 3.9 Table extension support arm 4 Tool-holders and tools 4.1 Cutterblock 4.2 Cutterblock wedge 4.3 Blade 5 Workheads and tool drives 5.1 Cutterblock bearing 6 Controls 6.1 Starting switch 6.2 Isolating switch 6.3 Surfacing table rollers vertical adjustment 7 Thicknessing table vertical adjustment 7 Thicknessing table rollers vertical adjustment 6.6 Fence canting adjustment 6.7 Fence canting adjustment 6.8 Surfacing table drawback lock 6.9 Fence transverse lock 7 Safety devices 7.1 Cutterblock guard (bridge guard) 7.2 Cutterblock rear guard 7.3 Anti-kick-back fingers 7.4 Cut depth limiter 8 Miscellaneous 8.1 Dust extraction outlet 8.2 Access door to control gear	2	Feed of workpiece and/or tools
2.3 Thicknessing table rollers Table extension roller 2.5 Feed roller drive chain 2.6 Feed roller drive sprockets 2.7 Tensioning roller sprockets Speed reduction gearbox or variable speed gear 2.9 Outfeed roller drive sprockets 3 Workpiece; support clamp and guide 3.1 Thicknessing table 3.2 Infeed surfacing table 3.3 Surfacing table lip plates 3.4 Outfeed surfacing table 3.5 Canting fence 3.6 Fence gauge plates 3.7 Infeed pressure bar 3.8 Outfeed pressure bar 3.9 Table extension support arm 4 Tool-holders and tools 4.1 Cutterblock 4.2 Cutterblock wedge Blade 5 Workheads and tool drives 5.1 Cutterblock bearing 6 Controls 6.1 Starting switch 6.2 Isolating switch 6.3 Surfacing table vertical adjustment Thicknessing table vertical adjustment Thicknessing table vertical adjustment Thicknessing table rollers vertical adjustment Fence fine adjustment 6.6 Fence fine adjustment 6.7 Fence canting adjustment 6.8 Surfacing table drawback lock Fence transverse lock 7 Safety devices 7.1 Cutterblock guard (bridge guard) 7.2 Cutterblock rear guard 7.3 Anti-kick-back fingers 7.4 Cut depth limiter 8 Miscellaneous 8.1 Dust extraction outlet Access door to control gear	2.1	Infeed feed roller
2.4 Table extension roller 2.5 Feed roller drive chain 2.6 Feed roller drive sprockets 2.7 Tensioning roller sprockets 2.8 Speed reduction gearbox or variable speed gear 2.9 Outfeed roller drive sprockets 3 Workpiece; support clamp and guide 3.1 Thicknessing table 3.2 Infeed surfacing table 3.3 Surfacing table lip plates 3.4 Outfeed surfacing table 3.5 Canting fence 3.6 Fence gauge plates 3.7 Infeed pressure bar 3.8 Outfeed pressure bar 3.9 Table extension support arm 4 Tool-holders and tools 4.1 Cutterblock 4.2 Cutterblock wedge Blade 5 Workheads and tool drives 5.1 Cutterblock bearing 6 Controls 6.1 Starting switch 6.2 Isolating switch 6.3 Surfacing table vertical adjustment Thicknessing table vertical adjustment Thicknessing table rollers vertical adjustment Thicknessing table rollers vertical adjustment Thicknessing table rollers vertical adjustment Thicknessing table drawback lock Fence fine adjustment 6.6 Fence fine adjustment 6.7 Fence canting adjustment 6.8 Surfacing table drawback lock Fence transverse lock 7 Safety devices 7.1 Cutterblock guard (bridge guard) 7.2 Cutterblock rear guard 7.3 Anti-kick-back fingers 7.4 Cutterblock rear guard 8.1 Dust extraction outlet 8.2 Access door to control gear		•
2.6 Feed roller drive chain 2.6 Feed roller drive sprockets 2.7 Tensioning roller sprockets 2.8 Speed reduction gearbox or variable speed gear 2.9 Outfeed roller drive sprockets 3 Workpiece; support clamp and guide 3.1 Thicknessing table 3.2 Infeed surfacing table 3.3 Surfacing table lip plates 3.4 Outfeed surfacing table 3.5 Canting fence Fence gauge plates 3.7 Infeed pressure bar 3.8 Outfeed pressure bar 3.9 Table extension support arm 4 Tool-holders and tools 4.1 Cutterblock 4.2 Cutterblock wedge 4.3 Blade 5 Workheads and tool drives 5.1 Cutterblock bearing 6 Controls 6.1 Starting switch 6.2 Isolating switch 6.3 Surfacing table vertical adjustment 7 Thicknessing table vertical adjustment 6.6 Fence fine adjustment 6.6 Fence fine adjustment 6.7 Fence canting adjustment 6.8 Surfacing table drawback lock 6.9 Fence transverse lock 7 Safety devices 7.1 Cutterblock guard (bridge guard) 7.2 Cutterblock rear guard 7.3 Anti-kick-back fingers 7.4 Cut depth limiter 8 Miscellaneous 8.1 Dust extraction outlet 8.2 Access door to control gear		5
2.6 2.7 Tensioning roller sprockets 2.8 Speed reduction gearbox or variable speed gear 2.9 Outfeed roller drive sprockets 3 Workplece; support clamp and guide 3.1 Thicknessing table 3.2 Infeed surfacing table 3.3 Surfacing table lip plates 3.4 Outfeed surfacing table 3.5 Canting fence 3.6 Fence gauge plates 3.7 Infeed pressure bar 3.8 Outfeed pressure bar 3.9 Table extension support arm 4 Tool-holders and tools 4.1 Cutterblock 4.2 Cutterblock wedge 4.3 Blade 5 Workheads and tool drives 5.1 Cutterblock bearing 6 Controls 6.1 Starting switch 6.2 Isolating switch 6.3 Surfacing table vertical adjustment 7 Thicknessing table vertical adjustment 6.6 Fence fine adjustment 6.7 Fence canting adjustment 6.8 Surfacing table drawback lock 6.9 Fence transverse lock 7 Safety devices 7.1 Cutterblock guard (bridge guard) 7.2 Cutterblock rear guard 7.3 Anti-kick-back fingers 7.4 Cut depth limiter 8 Miscellaneous 8.1 Dust extraction outlet 8.2 Access door to control gear	_	
2.7 Tensioning roller sprockets Speed reduction gearbox or variable speed gear 2.9 Outfeed roller drive sprockets 3 Workpiece; support clamp and guide 3.1 Thicknessing table 1.2 Infeed surfacing table 3.2 Infeed surfacing table 3.3 Surfacing table lip plates 3.4 Outfeed surfacing table 3.5 Canting fence 3.6 Fence gauge plates 3.7 Infeed pressure bar 3.8 Outfeed pressure bar 3.9 Table extension support arm 4 Tool-holders and tools 4.1 Cutterblock 4.2 Cutterblock wedge Blade 5 Workheads and tool drives 5.1 Cutterblock bearing 6 Controls 6.1 Starting switch 6.2 Isolating switch 6.3 Surfacing table vertical adjustment 6.4 Thicknessing table vertical adjustment 6.5 Thicknessing table rollers vertical adjustment 6.6 Fence fine adjustment 6.7 Fence canting adjustment 6.8 Surfacing table drawback lock 6.9 Fence transverse lock 7 Safety devices 7.1 Cutterblock guard (bridge guard) 7.2 Cutterblock rear guard 7.3 Anti-kick-back fingers 7.4 Cut depth limiter 8 Miscellaneous Dust extraction outlet Access door to control gear		
2.8 Speed reduction gearbox or variable speed gear 2.9 Outfeed roller drive sprockets 3 Workpiece; support clamp and guide 3.1 Thicknessing table 1.1 Infeed surfacing table 3.2 Infeed surfacing table 3.3 Surfacing table lip plates 3.4 Outfeed surfacing table 3.5 Canting fence 3.6 Fence gauge plates 3.7 Infeed pressure bar 3.8 Outfeed pressure bar 3.9 Table extension support arm 4 Tool-holders and tools 4.1 Cutterblock 4.2 Cutterblock wedge 8 Blade 5 Workheads and tool drives Cutterblock bearing 6 Controls 5.1 Cutterblock bearing 6 Controls 6.1 Starting switch 1 Isolating switch 1 Surfacing table vertical adjustment 1 Thicknessing table vertical adjustment 1 Thicknessing table rollers vertical adjustment 1 Thicknessing table drawback lock 1 Fence fine adjustment 1 Fence canting adjustment 1 Fence transverse lock 7 Safety devices 7.1 Cutterblock guard (bridge guard) 1 Cutterblock rear guard 1 Anti-kick-back fingers 1 Cut depth limiter 8 Miscellaneous 1 Dust extraction outlet 1 Access door to control gear		
speed gear Outfeed roller drive sprockets Workpiece: support clamp and guide 3.1 Thicknessing table Infeed surfacing table Infeed surfacing table Surfacing table lip plates Outfeed surfacing table Canting fence Signature of pence gauge plates Infeed pressure bar Outfeed pressure bar Outfeed pressure bar Table extension support arm Tool-holders and tools Cutterblock Cutterblock wedge Blade Workheads and tool drives Cutterblock bearing Controls Starting switch Isolating switch Surfacing table vertical adjustment Thicknessing table vertical adjustment Thicknessing table vertical adjustment Thicknessing table rollers vertical adjustment Fence fine adjustment Fence canting adjustment Surfacing table drawback lock Fence transverse lock Safety devices Cutterblock guard (bridge guard) Cutterblock rear guard Anti-kick-back fingers Cut depth limiter Miscellaneous Dust extraction outlet Access door to control gear	_	,
3.1 Thicknessing table 3.2 Infeed surfacing table 3.3 Surfacing table lip plates 3.4 Outfeed surfacing table 3.5 Canting fence 3.6 Fence gauge plates 3.7 Infeed pressure bar 3.8 Outfeed pressure bar 3.9 Table extension support arm 4 Tool-holders and tools 4.1 Cutterblock 4.2 Cutterblock wedge 8lade 5 Workheads and tool drives 6.1 Starting switch 6.2 Isolating switch 6.2 Isolating switch 6.3 Surfacing table vertical adjustment 6.4 Thicknessing table vertical adjustment 6.5 Thicknessing table rollers vertical adjustment 6.6 Fence fine adjustment 6.7 Fence canting adjustment 6.8 Surfacing table drawback lock 6.9 Fence transverse lock 7 Safety devices 7.1 Cutterblock guard (bridge guard) 7.2 Cutterblock rear guard 7.3 Anti-kick-back fingers 7.4 Cut depth limiter 8 Miscellaneous 8.1 Dust extraction outlet 8.2 Access door to control gear		speed gear
guide 3.1 Thicknessing table Infeed surfacing table 3.2 Surfacing table lip plates 3.4 Outfeed surfacing table 3.5 Canting fence 3.6 Fence gauge plates 3.7 Infeed pressure bar 3.8 Outfeed pressure bar 3.9 Table extension support arm 4 Tool-holders and tools 4.1 Cutterblock 4.2 Cutterblock wedge Blade 5 Workheads and tool drives Cutterblock bearing 6 Controls 6.1 Starting switch 6.2 Isolating switch 6.3 Surfacing table vertical adjustment Thicknessing table vertical adjustment Thicknessing table rollers vertical adjustment Thicknessing table rollers vertical adjustment 6.6 Fence fine adjustment 6.7 Fence canting adjustment 6.8 Surfacing table drawback lock Fence transverse lock 7 Safety devices 7.1 Cutterblock guard (bridge guard) Cutterblock rear guard Anti-kick-back fingers Cut depth limiter 8 Miscellaneous B.1 Dust extraction outlet Access door to control gear	2.9	Outfeed roller drive sprockets
3.1 3.2 3.3 3.4 3.4 3.5 3.4 3.5 3.6 3.6 3.7 3.8 3.9 3.9 3.9 3.9 4 4 4 4 5 5 5 6 6 6 6 6 6 6 7 6 6 6 6 6 6 6 6 6	3	1
3.3 3.4 3.4 3.5 Cutfeed surfacing table Canting fence Fence gauge plates 3.7 Infeed pressure bar 3.8 Outfeed pressure bar 3.9 Table extension support arm 4 Tool-holders and tools Cutterblock Cutterblock wedge Blade 5 Workheads and tool drives Cutterblock bearing 6 Controls 6.1 Starting switch 6.2 Isolating switch 6.3 Surfacing table vertical adjustment Thicknessing table vertical adjustment Thicknessing table rollers vertical adjustment Fence fine adjustment Fence canting adjustment Surfacing table drawback lock Fence transverse lock 7 Safety devices 7.1 Cutterblock guard (bridge guard) Cutterblock rear guard Anti-kick-back fingers Cut depth limiter Miscellaneous B.1 B.2 Dust extraction outlet Access door to control gear	3.1	, -
3.4 3.5 3.6 3.6 3.7 3.8 3.7 3.8 3.9 3.9 3.9 4 4 4 4 501-holders and tools 4.1 4.2 4.3 5 6 6 6 6 7 6 6 7 6 7 7 1 6 8 8 8 1 8 8 8 8 9 8 8 8 9 8 8 9 8 8 9 8 8 9 8 8 9 8 8 9 8 8 9 8 8 9 8 8 9 8 9 8 9 8 9 8 9 8 9 8 9 8 9 8 9 8 9 8 9 8 9 8 9 8 9 8 9 9 8 9 9 8 9 9 8 9 9 8 9 9 8 9 9 8 9 9 9 8 9 9 9 9 8 9 9 9 9 9 8 9		1
3.5 Canting fence Fence gauge plates 3.7 Infeed pressure bar 3.8 Outfeed pressure bar 3.9 Table extension support arm 4 Tool-holders and tools 4.1 Cutterblock 4.2 Cutterblock wedge 4.3 Blade 5 Workheads and tool drives 5.1 Cutterblock bearing 6 Controls 6.1 Starting switch 6.2 Isolating switch 6.3 Surfacing table vertical adjustment Thicknessing table vertical adjustment Thicknessing table rollers vertical adjustment 6.6 Fence fine adjustment 6.7 Fence canting adjustment 6.8 Surfacing table drawback lock Fence transverse lock 7 Safety devices 7.1 Cutterblock guard (bridge guard) Cutterblock rear guard Anti-kick-back fingers 7.4 Cut depth limiter 8 Miscellaneous 8.1 Dust extraction outlet Access door to control gear	_	
3.6 3.7 3.8 3.9 Table extension support arm 4 Tool-holders and tools 4.1 Cutterblock 4.2 Cutterblock wedge Blade 5 Workheads and tool drives Cutterblock bearing 6 Controls 6.1 Starting switch 6.2 Isolating switch 6.3 Surfacing table vertical adjustment Thicknessing table vertical adjustment Thicknessing table rollers vertical adjustment Fence fine adjustment 6.6 Fence fine adjustment Surfacing table drawback lock Fence transverse lock 7 Safety devices 7.1 Cutterblock guard (bridge guard) Cutterblock rear guard Anti-kick-back fingers Cut depth limiter 8 Miscellaneous B.1 B.2 Dust extraction outlet Access door to control gear		
3.8 3.9 Cutfeed pressure bar Table extension support arm Tool-holders and tools Cutterblock Cutterblock wedge Blade Workheads and tool drives Cutterblock bearing Controls Starting switch Surfacing table vertical adjustment Thicknessing table vertical adjustment Thicknessing table rollers vertical adjustment Fence fine adjustment Fence canting adjustment Surfacing table drawback lock Fence transverse lock Safety devices Cutterblock guard (bridge guard) Cutterblock rear guard Anti-kick-back fingers Cut depth limiter Miscellaneous B.1 Dust extraction outlet Access door to control gear		· · · · · · · · · · · · · · · · · · ·
Table extension support arm Tool-holders and tools Cutterblock Cutterblock wedge Blade Workheads and tool drives Cutterblock bearing Cutterblock bearing Controls Starting switch Surfacing table vertical adjustment Thicknessing table vertical adjustment Thicknessing table rollers vertical adjustment Fence fine adjustment Fence canting adjustment Surfacing table drawback lock Fence transverse lock Safety devices Cutterblock guard (bridge guard) Cutterblock rear guard Anti-kick-back fingers Cut depth limiter Miscellaneous B.1 B.2 Dust extraction outlet Access door to control gear	3.7	Infeed pressure bar
4 Tool-holders and tools 4.1 Cutterblock 4.2 Cutterblock wedge Blade 5 Workheads and tool drives 5.1 Cutterblock bearing 6 Controls 6.1 Starting switch 6.2 Isolating switch 6.3 Surfacing table vertical adjustment Thicknessing table vertical adjustment Thicknessing table rollers vertical adjustment 6.6 Fence fine adjustment 6.7 Fence canting adjustment 6.8 Surfacing table drawback lock Fence transverse lock 7 Safety devices 7.1 Cutterblock guard (bridge guard) 7.2 Cutterblock rear guard 7.3 Anti-kick-back fingers 7.4 Cut depth limiter 8 Miscellaneous 8.1 Dust extraction outlet Access door to control gear	_	1
4.1 4.2 4.3 Cutterblock 4.2 4.3 Blade Workheads and tool drives 5.1 Cutterblock bearing Controls 6.1 Starting switch 6.2 Isolating switch 6.3 Surfacing table vertical adjustment Thicknessing table vertical adjustment Thicknessing table rollers vertical adjustment Fence fine adjustment Fence canting adjustment Surfacing table drawback lock Fence transverse lock Safety devices Cutterblock guard (bridge guard) Cutterblock rear guard Anti-kick-back fingers Cut depth limiter Miscellaneous B.1 B.2 Morkheads wedge Blade Cutterblock paring Workheads and tool drives Cutterblock paring Adjustment Fence adjustment Fence canting adjustment Fence transverse lock Miscellaneous B.1 Cutterblock guard (bridge guard) Cutterblock rear guard Anti-kick-back fingers Cut depth limiter	3.9	Table extension support arm
4.2 4.3 Blade Workheads and tool drives Cutterblock bearing Controls Controls Starting switch Isolating switch Surfacing table vertical adjustment Thicknessing table vertical adjustment Thicknessing table rollers vertical adjustment Fence fine adjustment Fence eanting adjustment Surfacing table drawback lock Fence transverse lock Safety devices Cutterblock guard (bridge guard) Cutterblock rear guard Anti-kick-back fingers Cut depth limiter Miscellaneous B.1 Dust extraction outlet Access door to control gear		
4.3 Blade Workheads and tool drives Cutterblock bearing Controls Starting switch Surfacing table vertical adjustment Thicknessing table vertical adjustment Thicknessing table rollers vertical adjustment Fence fine adjustment Fence canting adjustment Surfacing table drawback lock Fence transverse lock Safety devices Cutterblock guard (bridge guard) Cutterblock rear guard Anti-kick-back fingers Cut depth limiter Miscellaneous B.1 Dust extraction outlet Access door to control gear		
5.1 Cutterblock bearing 6 Controls 6.1 Starting switch 6.2 Isolating switch 6.3 Surfacing table vertical adjustment Thicknessing table vertical adjustment Thicknessing table rollers vertical adjustment Fence fine adjustment Fence canting adjustment Surfacing table drawback lock Fence transverse lock 7 Safety devices 7.1 Cutterblock guard (bridge guard) 7.2 Cutterblock rear guard Anti-kick-back fingers 7.4 Cut depth limiter 8 Miscellaneous 8.1 Dust extraction outlet Access door to control gear		
5.1 Cutterblock bearing 6 Controls 6.1 Starting switch 6.2 Isolating switch 6.3 Surfacing table vertical adjustment Thicknessing table vertical adjustment Thicknessing table rollers vertical adjustment Fence fine adjustment Fence canting adjustment Surfacing table drawback lock Fence transverse lock 7 Safety devices 7.1 Cutterblock guard (bridge guard) 7.2 Cutterblock rear guard Anti-kick-back fingers 7.4 Cut depth limiter 8 Miscellaneous 8.1 Dust extraction outlet Access door to control gear	5	Workheads and tool drives
6.1 Starting switch 6.2 Isolating switch 6.3 Surfacing table vertical adjustment 6.4 Thicknessing table vertical adjustment Thicknessing table rollers vertical adjustment 6.6 Fence fine adjustment 6.7 Fence canting adjustment 6.8 Surfacing table drawback lock 6.9 Fence transverse lock 7 Safety devices 7.1 Cutterblock guard (bridge guard) 7.2 Cutterblock rear guard 7.3 Anti-kick-back fingers 7.4 Cut depth limiter 8 Miscellaneous 8.1 Dust extraction outlet Access door to control gear	_	1
6.2 Isolating switch 6.3 Surfacing table vertical adjustment Thicknessing table vertical adjustment Thicknessing table rollers vertical adjustment Fence fine adjustment Fence canting adjustment Surfacing table drawback lock Fence transverse lock 7 Safety devices 7.1 Cutterblock guard (bridge guard) 7.2 Cutterblock rear guard 7.3 Anti-kick-back fingers 7.4 Cut depth limiter 8 Miscellaneous 8.1 Dust extraction outlet Access door to control gear	6	Controls
6.3 6.4 6.4 6.5 Thicknessing table vertical adjustment Thicknessing table rollers vertical adjustment Fence fine adjustment Fence canting adjustment Surfacing table drawback lock Fence transverse lock 7 Safety devices 7.1 Cutterblock guard (bridge guard) Cutterblock rear guard Anti-kick-back fingers 7.4 Cut depth limiter 8 Miscellaneous B.1 Dust extraction outlet Access door to control gear	6.1	Starting switch
6.4 6.5 Thicknessing table vertical adjustment Thicknessing table rollers vertical adjustment Fence fine adjustment Fence canting adjustment Surfacing table drawback lock Fence transverse lock 7 Safety devices 7.1 Cutterblock guard (bridge guard) 7.2 Cutterblock rear guard Anti-kick-back fingers 7.4 Cut depth limiter 8 Miscellaneous 8.1 Dust extraction outlet Access door to control gear	T	
Thicknessing table rollers vertical adjustment 6.6 Fence fine adjustment 6.7 Fence canting adjustment 6.8 Surfacing table drawback lock 6.9 Fence transverse lock 7 Safety devices 7.1 Cutterblock guard (bridge guard) 7.2 Cutterblock rear guard 7.3 Anti-kick-back fingers 7.4 Cut depth limiter 8 Miscellaneous 8.1 Dust extraction outlet 8.2 Access door to control gear	1	
6.6 6.7 Fence fine adjustment Fence canting adjustment Surfacing table drawback lock Fence transverse lock 7 Safety devices Cutterblock guard (bridge guard) Cutterblock rear guard Anti-kick-back fingers Cut depth limiter 8 Miscellaneous B.1 Dust extraction outlet Access door to control gear		
6.7 6.8 6.9 Fence canting adjustment Surfacing table drawback lock Fence transverse lock 7 Safety devices 7.1 Cutterblock guard (bridge guard) Cutterblock rear guard Anti-kick-back fingers Cut depth limiter 8 Miscellaneous 8.1 Dust extraction outlet Access door to control gear		1 -
6.8 6.9 Surfacing table drawback lock Fence transverse lock 7 Safety devices 7.1 Cutterblock guard (bridge guard) Cutterblock rear guard Anti-kick-back fingers Cut depth limiter 8 Miscellaneous 8.1 Dust extraction outlet Access door to control gear		1
6.9 Fence transverse lock 7 Safety devices 7.1 Cutterblock guard (bridge guard) 7.2 Cutterblock rear guard Anti-kick-back fingers Cut depth limiter 8 Miscellaneous 8.1 Dust extraction outlet Access door to control gear		
7.1 Cutterblock guard (bridge guard) 7.2 Cutterblock rear guard 7.3 Anti-kick-back fingers 7.4 Cut depth limiter 8 Miscellaneous 8.1 Dust extraction outlet Access door to control gear		
7.2 Cutterblock rear guard 7.3 Anti-kick-back fingers 7.4 Cut depth limiter 8 Miscellaneous 8.1 Dust extraction outlet 8.2 Access door to control gear	7	Safety devices
7.3 Anti-kick-back fingers 7.4 Cut depth limiter 8 Miscellaneous 8.1 Dust extraction outlet 8.2 Access door to control gear		
7.4 Cut depth limiter 8 Miscellaneous 8.1 Dust extraction outlet Access door to control gear	1	,
8.1 Dust extraction outlet 8.2 Access door to control gear	1	<u> </u>
8.2 Access door to control gear	8	Miscellaneous
,		1
5.3 Scale for thicknessing	I .	_
		_
9 (clause free)		
10 Examples of work	1	1
10.1 Thicknessing 10.2 Planing		

5 Acceptance conditions and permissible deviations — Geometrical tests

No.	Diagram	Object	Permissible deviations	Measuring instruments	Observations and references in ISO 230/1 test code
G1		Checking of flatness of the tables: a) longitudinal straightness b) diagonal straightness c) transverse straightness	a) and b) $0,10$ for $A \le 630$ $0,20$ for $630 < A \le 1250$ $0,30$ for $A > 1250$ c) $0,10$ for $B \le 400$ $0,15$ for $B > 400$	Straightedge and feeler gauges	Clauses 5.212 and 5.322.
G2		Parallelism of the two surface planing tables longitudinally	$C = 5$ 0,10 for $D \le 1250$ 0,25 for 1 250 < $D \le 2500$ 0,40 for $D > 2500$	Straightedge, slip gauges and feeler gauges	Flat to convex.

1

No.	Diagram	Object	Permissible deviations	Measuring instruments	Observations and references in ISO 230/1 test code
G6		Checking of parallelism of the cutterblock to the outfeed surface planing table	0,10 where the blades setting device is not carried from the cutterblock 0,05 where the blades setting device is carried from the cutterblock	Dial gauge	Clause 5.412.4
G7		Checking of flatness of the thicknessing table: a) longitudinal straightness b) diagonal straightness c) transverse straightness	a) and b) 0,20 for $H < 1000$ 0,30 for $H > 1000$ c) 0,10 for $I < 400$ 0,15 for $I > 400$	Straightedge and feeler gauges	Clauses 5.322 and 5.212 For verification c) check in two places each about 50 mm on either side of the sutterblock.

No.	Diagram	Object	Permissible deviations	Measuring instruments	Observations and references in ISO 230/1 test code
G8		Checking of parallelism of the thicknessing table in upper and lower positions to the cutterblock	0,10 for $I < 400$ 0,15 for $I > 400$	Dial gauge	Clause 5.412.4
G9		Measuring of run-out of the thicknessing table rollers	0,15	Dial gauge	Clause 5.612.2 Checked at the end and centre of each roller.

No.	Diagram	Object	Permissible deviations	Measuring instruments	Observations and references in ISO 230/1 test code
G10	a)	Measuring of run-out of the horizontal cutterblock	0,03	Dial gauge	Clause 5.612.2 a) Where the blade setting device is carried from the block shoulders check the shoulders. b) Where the blade setting device is carried from the cutterblock check on the block.

Standard Mark

The use of the Standard Mark is governed by the provisions of the Bureau of Indian Standards Act, 1986 and the Rules and Regulations made thereunder. The Standard Mark on products covered by an Indian Standard conveys the assurance that they have been produced to comply with the requirements of that standard under a well defined system of inspection, testing and quality control which is devised and supervised by BIS and operated by the producer. Standard marked products are also continuously checked by BIS for conformity to that standard as a further safeguard. Details of conditions under which a licence for the use of the Standard Mark may be granted to manufacturers or producers may be obtained from the Bureau of Indian Standards.

Bureau of Indian Standards

BIS is a statutory institution established under the Bureau of Indian Standards Act, 1986 to promote harmonious development of the activities of standardization, marking and quality certification of goods and attending to connected matters in the country.

Copyright

BIS has the copyright of all its publications. No part of these publications may be reproduced in any form without the prior permission in writing of BIS. This does not preclude the free use, in the course of implementing the standard, of necessary details, such as symbols and sizes, type or grade designations. Enquiries relating to copyright be addressed to the Director (Publications), BIS.

Revision of Indian Standards

Indian Standards are reviewed periodically and revised, when necessary and amendments, if any, are issued from time to time. Users of Indian Standards should ascertain that they are in possession of the latest amendments or edition. Comments on this Indian Standard may be sent to BIS giving the following reference:

Doc: No. PE 01 (5342)

Amendments Issued Since Publication

Amend No.	Date of Issue	Text Affected
· · · · · · · · · · · · · · · · · · ·		
	BUREAU OF INDIAN STANDARDS	
Headquarters:		
Manak Bhavan, 9 Bahadur 8 Telephones: 331 01 31, 331	Shah Zafar Marg, New Delhi 110002 13 75	Telegrams: Manaksanstha (Common to all Offices)
Regional Offices:		Telephone
Central: Manak Bhavan, 9 I NEW DELHI 1100		\$331 01 31 331 13 75
Eastern: 1/14 C. I. T. Schen CALCUTTA 70003	ne VII M, V. I. P. Road, Maniktola 54	37 84 99, 37 85 61 37 86 26, 37 86 62
Northern: SCO 445-446, Sec	tor 35-C, CHANDIGARH 160036	\$53 38 43, 53 16 40 53 23 84
Southern: C. I. T. Campus,	IV Cross Road, MADRAS 600113	\$235 02 16, 235 04 42 235 15 19, 235 23 15
Western: Manakalaya, E9 BOMBAY 400093	MIDC, Marol, Andheri (East)	632 92 95, 632 78 58 632 78 91, 632 78 92
FARIDABAD. G	BANGALORE. BHOPAL. BHUBAN GHAZIABAD. GUWAHATI. HYDER TNA. THIRUVANANTHAPURAM.	NESHWAR. COIMBATORE. ABAD. JAIPUR. KANPUR.